

1. Main Console

1. Main Console



This is the main operation system - to activate, schedule recording, setup smart guard and configure system setting.

